## WOODSHOP WORKFLOW DIAGRAM EXAMPLE

CREATE YOUR OWN WORKFLOW DIAGRAM BASED ON YOUR MOST COMMON PROJECTS. IN FACT, DO THIS FOR SEVERAL OF YOUR MOST COMMON PROJECTS. IF YOU SEE CERTAIN BLOCKS OF TASKS REPEATING THEMSELVES, MAKE SURE YOUR LAYOUT FOLLOWS THAT ORDER. IF SOME TASKS SEEM TO ALWAYS VARY, THOSE STATIONS COULD BE MADE TO BE MOBILE, OR PUT OUT OF THE GENERAL WORKFLOW ALTOGETHER.

GIVE YOURSELF A FEW "OPEN" AREAS IN YOUR SHOP IF YOU HAVE THE ROOM, SO YOU CAN STAGE LARGE PROJECTS, OR PUT ANOTHER PROJECT THERE SO YOU CAN WORK ON ANOTHER

© 2012 www.The Art of Woodshop Design.com

EXAMPLE: IF YOU USE GLUED-UP PANELS, YOU MAY GO TO YOUR WORKBENCH OR ASSEMBLY TALBE AFTER THE PLANER FOR GLUING, THEN HEAD TO WIDE BELT OR DRUM SANDER, THE TABLE SAW, AND FINALLY THE ROUTER TABLE.

THINK ABOUT YOUR WORKFLOW FOR PRODUCING PANELS, DOORS, TABLE TOPS, LEGS, APRONS, AND OTHER COMMON PARTS OF YOUR PROJECTS. DETERMINE YOUR PRIORITIES AND ARRANGE MEACHINES TO ACCOMMODATE THE MOST COMMON PROCESSES. THERE WILL BE COMPROMISES, BUT IF YOU CLUSTER MACHINES USED FOR EACH PROCESS (STOCK BREAKDOWN, S4S, JOINERY/ SHAPING, ETC.) TOGETHER . YOU'LL DO LESS HUSTLING AROUND THE WORKSHOP. WOOD PREF TORAGE & OR RADIAL & STOCK MILLING, S4 REGULAR STOCK BOARDS ROUGH RIP ONE SIDE LENGTH OR ADJACENT PARALLEL SQUARE ONE END SIDES/ FACES AND TRIM TO VENEERING PANEL STOCK FINAL WIDTH OR LENGTH RESAW BANDSAW OR TABLE SAW ROUTER TABLE OR SHAPING/ 14" BANDSAV FACE(S) PARALLE AND-HELD CLAMPS, OWNDRAF FINISH PREP GLUE, **FINISHING** PLANES ASTENERS HARDWARE IANDEL ANE the art of Wo DRUM